




2-BURNER ASSEMBLY
 (for Input of 199 KBtu/H or less)



3-BURNER ASSEMBLY
 (for Input of 250 KBtu/H or higher)



CONTROL PANEL



BLOWER ASSEMBLY

Item	Parts Description	BTL 120, 154, 180, 198, 199	BTL 250(A), 275(A)	BTL 310(A), 366(A), 400(A)
1	Gas Valve	9008884005	9008885005	9008885005
2	Blower	9008886005	9008887005	9008887005
3	Power Relay - Blower	9008888005	9008888005	9008888005
4	Gasket - Burner	9008889015	9008983005	9008983005
5	Gasket - Skirt Ring	9008890015	9008890015	9008890015
6	Insulation Board	9008891005	9008984005	9008984005
7	Ignition Pilot Assembly	9008892005	9008892005	9008892005
8	Burner	9008893005	9008986005	9008986005
9	Thermostat, Digital	9004570205	9004570205	9004570205
10	Ignition Control	9009033005	9009033005	9009033005
11	Lower Temperature Probe	9006160215	9006160215	9006160215
12	Drain Valve	9003907015	9003907015	9003907015
13	The Eliminator	9006051205	9006051205	9006051205
14	Gasket, Cleanout	9004099215	9004099215	9004099215
15	Valve, T&P	9005899205	9005924205	9005924205
16	Anode	9000029005	9000029005	9000029005
17	Collar, Pipe Nipple	9005783205	9005783205	9005783205
18	Probe/ECO, Upper	9008835015	9008835015	9008835015
19	Switch, Blower Prover	9008471015	9008471015	9008471015
20	Switch, Gas Supply	-----	-----	9003184005

To Order A Complete Burner System	
BTL 120 Complete Burner System	9009003005
BTL 154 Complete Burner System	9009004005
BTL 180 Complete Burner System	9009005005
BTL 198 & 199 Complete Burner System	9009006005
BTL 250 Complete Burner System	9009007005
BTL 275 Complete Burner System	9009008005
BTL 310 Complete Burner System	9009009005
BTL 366 Complete Burner System	9009010005
BTL 400 Complete Burner System	9009011005



A.O. Smith Water Heater Parts Fulfillment
125 Southeast Parkway
Franklin, TN 37068
1-800-433-2545
www.hotwater.com